

















22084258

Load Sensing Valve Settings LSV type BR 5607

| Axle load (kg) axle no. | deflection (mm) Bellow press. (bar) | inlet press. (bar) | outlet press. (bar) | cylinder pressure (bar) |
|----------------------------|---|-----------------------|------------------------|----------------------------|
| 2500 | 1,6 | 6 | 2,4 | |
| 3000 | 2,1 | 6 | 2,7 | |
| 4000 | 3,2 | 6 | 3,4 | |
| 6000 | 5,4 | 6 | 4,9 | |
| 8000 | 7,5 | 6 | 6 | |
| 10000 | 7,5 | 6 | 6 | |



Order no. 366125

Length L = deflection F =

Printing date 09-02-2006